



PROGRAMMING TIME AND/OR DATE ON THE TELEPHONE SYSTEM

- **PRESS PROGRAM**
- **DIAL ****
- **DIAL 1234** (SYSTEM PASSWORD)
- **DIAL 000** (DATE AND TIME PROGRAM NUMBER)
- **PRESS THE ENTER KEY**
- **ENTER THE YEAR 00-99 OR PRESS THE RIGHT ARROW ON NAVIGATOR KEY**
- **ENTER THE MONTH 01-12**
- **PRESS THE RIGHT ARROW ON NAVIGATOR KEY**
- **ENTER THE DAY OF THE MONTH 01-31**
- **PRESS THE ENTER KEY**
- **PRESS THE NEXT (DOWN ARROW) KEY**
- **ENTER THE HOUR 01-12**
- **PRESS THE RIGHT ARROW**
- **ENTER THE MINUTES 00-59**
- **PRESS THE RIGHT ARROW**
- **PRESS THE SELECT (AUTO ANS/MUTE) KEY FOR AM OR PM**
- **PRESS THE ENTER KEY**
- **PRESS THE HOLD KEY**
- **PRESS THE EXIT KEY TO EXIT PROGRAMMING**