



TOSHIBA CIX DATE & TIME ADJUSTMENT

DATE

1. From main/reception telephone, leave the handset down and press **#651**
2. Enter the date as **YY/MM/DD**
3. Press **#** key
4. Press **SPKR** key

TIME

1. From main/reception telephone, leave the handset down and press **#652**
2. Enter the time as **HH/MM/SS** in the 24 hour clock format
3. Press **#** key
4. Press **SPKR** key